

Getting started with Pi camera

For course EE592P, IoT Lab.

By, Joe Johnson

Source- <https://projects.raspberrypi.org/en/projects/getting-started-with-picamera>

What you will learn


➔Raspberry Pi Camera Module, using Python and picamera. pictures, record video, and apply image effects.

➔What you will learn

- How to connect the Camera Module to the Raspberry Pi
- How to use Python to control the Camera Module
- How to use `start_preview()` and `stop_preview()` to control the camera preview
- How to take still pictures with `capture()`
- How to record video with `start_recording()` and `stop_recording()`
- How to play back video with `omxplayer`
- How to alter the brightness and contrast
- How to apply image effects and exposure modes

Connect the Camera Module


- Hardware – Raspberry Pi Camera Module
- Can take Pictures and Record video in full HD.
- How to connect the Camera Module
 - Switch off Pi
 - Connect camera to Pi's camera port, locate the camera port and connect the camera:




Software Configuration

→ Start up the Pi

→ Open the Raspberry Pi Configuration Tool from the Main menu:



→ Ensure the camera software is enabled:



→ Reboot the Pi

Camera Preview

→ Open Python 3 from the main menu:

```
from picamera import PiCamera
from time import sleep

camera = PiCamera()

camera.start_preview()
sleep(10)
camera.stop_preview()
```

→ Note that the camera preview only works when a monitor is connected to the Pi, so remote access (such as SSH and VNC) will not allow you to see the camera preview

Rotate Image

→ If your preview was upside-down, you can rotate it with the following code:

→ You can rotate the image by 90, 180, or 270 degrees, or you can set it to 0 to reset.

→ You can alter the transparency of the camera preview by setting an alpha level:

→ alpha can be any value between 0 and 255.

```
camera.rotation = 180
camera.start_preview()
sleep(10)
camera.stop_preview()
```

```
from picamera import PiCamera
from time import sleep

camera = PiCamera()

camera.start_preview(alpha=200)
sleep(10)
camera.stop_preview()
```

Still pictures

→ Amend your code to reduce the sleep and add a `camera.capture()` line:

```
camera.start_preview()  
sleep(5)  
camera.capture('/home/pi/Desktop/image.jpg')  
camera.stop_preview()
```

→ It's important to sleep for at least 2 seconds before capturing, to give the sensor time to set its light levels.

→ Now try adding a loop to take five pictures in a row:

```
camera.start_preview()  
for i in range(5):  
    sleep(5)  
    camera.capture('/home/pi/Desktop/image%s.jpg' % i)  
camera.stop_preview()
```

Recording video

→ Amend your code to replace `capture()` with `start_recording()` and `stop_recording()`:

```
camera.start_preview()  
camera.start_recording('/home/pi/video.h264')  
sleep(10)  
camera.stop_recording()  
camera.stop_preview()
```

→ To play the video, you'll need to open a terminal window by clicking the black monitor icon in the taskbar:

```
omxplayer video.h264
```

→ Type the following command and press Enter to play the video:

→ The video should play. It may actually play at a faster speed than what has been recorded, due to omxplayer's fast frame rate.